



Elevator Equipment Corporation
"Simplicity in Motion"

EECOLUBE HYDRAULIC OIL ADDITIVE

High Performance Oil Additive formulated to reduce "Stick Slip"

- Extremely effective in relieving "stick slip" on noisy hydraulic pistons.
- Eliminates "chattering"
- Improves load bearing capacity
- Improves hydraulic oil flow characteristics
- Unique polar chemical boundary lubricant improves hydraulic oil operating performance
- Does not contain Teflon, graphite, molybdenum disulfide, or any other solid lubricants



Description

EECOLube is a performance improving friction modifying oil additive formulated to reduce "Stick Slip", rough starts & stops, and prevent noise in hydraulic elevator systems. EECOLube is not meant to fix all issues associated with hydraulic elevators, but has been proven to greatly improve ride performance under demanding conditions. EECOLube is compatible with petroleum or biodegradable oils. EECO recommends using 1 bottle (quart) per 60 gallons of oil.

"Stick Slip" – Refers to the phenomenon of a spontaneous jerking motion that can occur while two objects are sliding over each other.

Features & Benefits

- Extremely effective in relieving the "stick slip" on noisy hydraulic pistons.
- Eliminates "chattering"
- Improves load bearing capacity
- Improves hydraulic oil flow characteristics
- Unique polar chemical boundary lubricant improves hydraulic oil operating performance
- Does not contain Teflon, graphite, molybdenum disulfide or any other solid lubricants

Available from Elevator Equipment per Quart or in a case of 4 Quarts

Directions & Warnings

Directions:

Add one bottle (quart) directly into the hydraulic elevator system.

Run elevator for ten minutes.

if noise persists add an additional quart.

Warning:

For use in Hydraulic Elevator Systems only. DO NOT use in gearbox, steering clutch, or brake systems.

Always use protective gear when using EECOLube. Avoid contact with skin and eyes. For contact with skin wash with soap and water. For contact with eyes, flush eyes for 15 minutes & seek medical attention.

DO NOT ingest EECOLube.

Complete MSDS Sheet available at www.elevatorequipment.com

